

# 100G QSFP28 to 25G SFP28 Adapter

# 

# **QSFP28 Series**

- Easy installation
- Compliant with SFF-8665
- Compliant with SFF-4832
- 1 independent duplex channel operating at 25 Gbps
- All-metal housing for superior
  EMI performance
- 100 Ω differential impedance system
- Low insertion loss
- Low crosstalk
- RoHS compliant

Ascent's QSFP28 to SFP28 Adapter (QSA) Module offers 25 Gigabit Ethernet connectivity for Quad Small Form-Factor Pluggable (QSFP28)-only platforms. It allows smooth and cost-effective migration to 100 Gigabit Ethernet by providing an option to use lower-speed Enhanced Small Form-Factor Pluggable (SFP28) modules in empty QSFP28 ports or when the other end of the network is running at lower speeds.

The QSA Module converts a QSFP28 port into an SFP28 port. With this adapter, customers have the flexibility to use any SFP28 module or cable to connect to a lower-speed port on the other end of the network. This flexibility allows a costeffective transition to 100 Gigabit Ethernet by maximizing the use of high-density 100 Gigabit Ethernet QSFP28 platforms. This adapter supports all SFP28 optics and cable reaches, compatible switch models and SFP28 modules.


# 100G QSFP28 to 25G SFP28 Adapter



## **Key Features**

- Trouble-free installation and network bring-up
- Compliant to industry standards: SFF-8665 IEEE802.3bj / SFF-8432 IEEE-802.3by
- Precision process control for minimization of pair-to-pair skew
- 1 independent duplex channel operating at 25 Gbps
- Support for 5 Gbps, and 10 Gbps data rates
- All-metal housing for superior EMI performance
- 100 Ω differential impedance system
- Operating case temperature: 0 °C to 70°C
- Low insertion loss
- Low crosstalk
- Secure latching mechanism
- RoHS compliant

# **Outline Diagram**





## QSFP28 Pin Assignment-

#### **QSFP28 Host board Connector Pinout**



## Top Side Viewed from Top

### Bottom Side Viewed from Bottom

| Pin | Logic      | Symbol  | Name/Description                     | Note |
|-----|------------|---------|--------------------------------------|------|
| 1   |            | GND     | Ground                               | 1    |
| 2   | CML-I      | Tx2n    | Transmitter Inverted Data Input      |      |
| 3   | CML-I      | Тх2р    | Transmitter Non-Inverted Data output |      |
| 4   |            | GND     | Ground                               | 1    |
| 5   | CML-I      | Tx4n    | Transmitter Inverted Data Input      |      |
| 6   | CML-I      | Tx4p    | Transmitter Non-Inverted Data output |      |
| 7   |            | GND     | Ground                               | 1    |
| 8   | LVTLL-I    | ModSelL | Module Select                        |      |
| 9   | LVTLL-I    | ResetL  | Module Reset                         |      |
| 10  |            | VccRx   | + 3.3V Power Supply Receiver         | 2    |
| 11  | LVCMOS-I/O | SCL     | 2-Wire Serial Interface Clock        |      |
| 12  | LVCMOS-I/O | SDA     | 2-Wire Serial Interface Data         |      |
| 13  |            | GND     | Ground                               |      |
| 14  | CML-O      | Rx3p    | Receiver Non-Inverted Data Output    |      |
| 15  | CML-O      | Rx3n    | Receiver Inverted Data Output        |      |
| 16  |            | GND     | Ground                               | 1    |
| 17  | CML-O      | Rx1p    | Receiver Non-Inverted Data Output    |      |
| 18  | CML-O      | Rx1n    | Receiver Inverted Data Output        |      |
| 19  |            | GND     | Ground                               | 1    |
| 20  |            | GND     | Ground                               | 1    |
| 21  | CML-O      | Rx2n    | Receiver Inverted Data Output        |      |

# 100G QSFP28 to 25G SFP28 Adapter

| 22 | CML-0   | Rx2p    | Receiver Non-Inverted Data Output   |   |
|----|---------|---------|-------------------------------------|---|
| 23 |         | GND     | Ground                              | 1 |
| 24 | CML-0   | Rx4n    | Receiver Inverted Data Output       | 1 |
| 25 | CML-0   | Rx4p    | Receiver Non-Inverted Data Output   |   |
| 26 |         | GND     | Ground                              | 1 |
| 27 | LVTTL-O | ModPrsL | Module Present                      |   |
| 28 | LVTTL-O | IntL    | Interrupt                           |   |
| 29 |         | VccTx   | +3.3 V Power Supply transmitter     | 2 |
| 30 |         | Vcc1    | +3.3 V Power Supply                 | 2 |
| 31 | LVTTL-I | LPMode  | Low Power Mode                      |   |
| 32 |         | GND     | Ground                              | 1 |
| 33 | CML-I   | Тх3р    | Transmitter Non-Inverted Data Input |   |
| 34 | CML-I   | Tx3n    | Transmitter Inverted Data Output    |   |
| 35 |         | GND     | Ground                              | 1 |
| 36 | CML-I   | Tx1p    | Transmitter Non-Inverted Data Input |   |
| 37 | CML-I   | Tx1n    | Transmitter Inverted Data Output    |   |
| 38 |         | GND     | Ground                              | 1 |
|    |         |         |                                     |   |


#### Note:


1. GND is the symbol for signal and supply (power) common for QSFP modules. All are common within the QSFP module and all module voltages are referenced to this potential otherwise noted. Connect these directly to the host board signal common ground plane

2. VccRx, Vcc1, and VccTx are the receiver and transmitter power suppliers and shall be applied concurrently. Recommended host board power supply filtering is shown below. VccRx, Vcc1, and VccTx may be internally connected within the QSFP transceiver module in any combination. The connector pins are each rated for a maximum current of 500 mA.

## SFP28 Pin Assignment

#### SFP28 Host board Connector Pinout for SFP28





| Pin | Logic     | Symbol     | Name/Description                            | Note |
|-----|-----------|------------|---|------|
| 1   |           | VeeT       | Module Transmitter Ground                   | 1    |
| 2   | LVTTL-O   | Tx_Fault   | Transmitter Fault                           | 2    |
| 3   | LVTTL-I   | Tx_Disable | Transmitter Disable                         | 3    |
| 4   | LVTTL-I/O | SDA        | MOD-DEF2 2-wire serial interface data line  | 4    |
| 5   | LVTTL-I/O | SCL        | MOD-DEF1 2-wire serial interface clock line | 4    |
| 6   |           | Mod_Abs    | Module Absent                               | 5    |
| 7   | LVTTL-I   | RS0        | Rate Select Zero                            |      |
| 8   | LVTTL- O  | Rx_LOS     | Module Receiver Loss of Signal              | 2    |
| 9   | LVTTL-I   | RS1        | Rate Select One                             |      |
| 10  |           | VeeR       | Module Receiver Ground                      | 1    |
| 11  |           | VeeR       | Module Receiver Ground                      | 1    |
| 12  | CML-O     | RD-        | Receiver Inverted Data Output               |      |
| 13  | CML-O     | RD+        | Receiver Non-Inverted Data Output           |      |
| 14  |           | VeeR       | Module Receiver Ground                      | 1    |
| 15  |           | VccR       | Module Receiver 3.3V Supply                 |      |
| 16  |           | VccT       | Module Transmitter 3.3V Supply              |      |
| 17  |           | VeeT       | Module Transmitter Ground                   | 1    |
| 18  | CML-I     | TD+        | Transmitter Non-Inverted Data Input         |      |
| 19  | CML-I     | TD-        | Transmitter Inverted Data Input             |      |
| 20  |           | VeeT       | Module Transmitter Ground                   | 1    |

#### Notes:

1. The module signal grounds, VeeR and VeeT, shall be isolated from the module case.

# 100G QSFP28 to 25G SFP28 Adapter



2. This is an open collector/drain output and shall be pulled up with 4.7 k $\Omega$  – 10 k $\Omega$  to Vcc\_Host on the host board. Pull ups can be connected to multiple power supplies, however the host board design shall ensure that no module has voltage exceeding module VccT/R + 0.5 V.

- 3. This is an open collector/drain input and shall be pulled up with 4.7 k $\Omega$  10 k $\Omega$  to VccT in the module.
- 4. See 2-wire electrical specifications.
- 5. This shall be pulled up with 4.7  $k\Omega$  10  $k\Omega$  to Vcc\_Host on the host board.

# Specifications-

#### **Recommended Operation Condition** Parameter Symbol Min Max Unit Note 70 °C Operating Case Temperature Тор 0 °C Storage Temperature Tst -40 85 **Relative Humidity** RS 85 Non-condensing % Supply Voltage Vcc3 3.15 3.45 V

# **Ordering Information**-

Product Name QSFP28-CVR-SFP28 **Product Description** 100G QSFP28 to 25G SFP28 Adapter Converter Module



## **Contact Information**





#### Ascent Communication Technology Ltd

#### AUSTRALIA

140 William Street, Melbourne Victoria 3000, AUSTRALIA Phone: +61-3-8691 2902

#### CHINA

Unit 1933, 600 Luban Road 200023, Shanghai CHINA Phone: +86-21-60232616

EUROPE Pfarrer-Bensheimer-Strasse 7a 55129 Mainz, GERMANY Phone: +49 (0) 6136 926 3246

WEB: <u>www.ascentcomtec.com</u>

#### HONG KONG SAR

Unit 9, 12<sup>th</sup> Floor, Wing Tuck Commercial Centre 177 Wing Lok Street, Sheung Wan, HONG KONG Phone: +852-2851 4722

#### USA

2710 Thomes Ave Cheyenne, WY 82001, USA Phone: +1-203 816 5188

#### VIETNAM

15 /F TTC Building, Duy Tan Street Cau Giay Dist., Hanoi, VIETNAM Phone: +84 243 795 5917

EMAIL: <a href="mailto:sales@ascentcomtec.com">sales@ascentcomtec.com</a>

Specifications and product availability are subject to change without notice. Copyright © 2022 Ascent Communication Technology Limited. All rights reserved. Ver. ACT\_QSFP28-CVR-SFP28\_Datasheet\_V1b\_Aug\_2022